




TOP AND CONSOLE PARTS

For Models: LGR7646JQ0, LGR7646JT0
(Designer White) (Biscuit)

GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS

For Models: LGR7646JQ0, LGR7646JT0

(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS	12	3978605	Hinge, R.H.	32	3396029	Wire-Jumper Assembly (Temperature)
	LIT3405338	Installation Instructions		3978606	Hinge, L.H.			
	LIT8314844	Use & Care Guide	13	688983	Screw, 8-18 x 5/8	39	3398095	Relay, Push-To-Start
	LIT3406692	Wiring Diagram	14	3397695	Wire, Jumper (Guard/On-Off)	40	3401144	Connector (PTS Relay)
2	3405156	Switch, Finish Guard	15	693995	Screw, Hex Head Top	48		Timer Knob Assembly
3	3394427	Clip, Harness		8271390	White		8312687	White
4		Cap, End (L.H.)		8271392	Biscuit		8271404	Biscuit
	8271365	White	17	3401684	Wire, Jumper (Black)	49		Knob, Push To Start
	8271368	Biscuit	18	3399639	Switch, Temperature		8271339	White
5	3397269	Connector (Timer)	19	297535	Bumper, Lint Lid		8271348	Biscuit
6	8274261	Panel, Rear Console	20	3400859	Screw, Grounding	50	717252	Receptacle, 2-Way
7	3395683	Housing, Connector (Motor)	21	8299766	Timer Assembly (60 Hz.)	51	3347243	Connector 6-Circuit
8		Cap, End (R.H.)	22	3403499	Connector, 2-Position (Gas Valve)	52	94614	Terminal, Female
	8271359	White				53	8271418	Bracket, Control Panel, Control
	8271362	Biscuit	23	3403498	Connector, 3-Position (Gas Valve)	54		White
9	694419	Buzzer, Mini					3977821	Biscuit
10	349639	Handle & Lint Screen Assembly	29	3390646	Screw, 8-18 x 5/16	70	3936144	Connector
11		Cover, Lint Screen	30	357213	Nut, Push-In (2)	76	388326	Screw, Console
	8283378	White	31	3394301	Harness, Wiring			
	8283380	Biscuit						


LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH-UP (1/2oz.)			PAINT, PRESSURIZED SPRAY (12 oz.)			Following May Be Purchased		
	72017	White		350930	White	DO-IT-YOURSELF REPAIR MANUALS		
	4392899	Biscuit		4392901	Biscuit		LIT677818	Dryer
				350938	Primer, Gray			
			PAINT, BULK (1 qt.)					
				799344	White (Uncut)			
				4392900	Biscuit(Uncut)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: LGR7646JQ0, LGR7646JT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS


For Models: LGR7646JQ0, LGR7646JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697776	Screw, 10–32 x 5/8 (External Ground)	23	685203	Clip, Felt Pad (2)	63	660658	Clamp, Motor
2	343641	Screw, 10–16 x 1/2	24	3389441	Catch, Door Assembly	64	3401775	Valve, Gas 60 Hz. (Complete)
3	3404162	Clamp, Motor (W/Shield)	25	3390731	Seal, Door	65	686590	Ignitor
4	238614	Bumper	26	337189	Clip, Hinge (2)	66	3393909	Lock Screw & Washer (8–32 x 5/8)
5	3396795	Cover, Block	27	342043	Screw, 10–32 x 3/8	67	3402844	Burner Assembly, 60 Hz. (See Pages 7 & 8 For Further Burner Breakdown)
6	693995	Screw, Hex Washer Head	28	8066056	Hinge, R.H.	68	341029	Clamp, Pipe
7	3396805	Panel, Rear	29	3394083	Clip, Front Panel	69	694572	Kit, Conversion Type 1, 2 & 3 To Type 4 (LPG)
10	3406107	Door Switch Assembly	33	696144	Strike, Panel	70	694539	Coil, 60 HZ. Split (3 Terminal) (Pilot Position)
11	697773	Screw, 6–20 x 7/8	35	695737	Door, Rear	71	694540	Coil, 60 HZ. (2 Terminal) (Main)
13	694091	Screw, 8–18 x 3/8	36	3393549	White Biscuit	72	694421	Screw, Bracket Mounting (8–32 X 1/2) 2
14	692495	Spring, Door (2)	37	3977241	Handle, Door	73	694538	Bracket, Coil
15	3357011	Screw, 10–16 x 1/2		690270	White Biscuit	74	694424	Leak Limiter
16	3392100	Foot, Dryer		3977242	Biscuit	75	694423	Screw, Regulator Adjustment
	279810	Foot – Optional (Extended Length Package Of 2 (Not Included))	38	3406129	Seal & Bearing Assembly	76	694422	Spring, Regulator
18		Cabinet (Includes Illus. No's. 5, 7, 16, 29 & 57)	45	344020	Cord, Power	79	239822	Plug, Pipe
	3399585	White Biscuit	49		Plug, Front Panel			
	3399595	Biscuit		3394975	White Biscuit			
19	98234	Clip, Ground (2)		3394978	Biscuit			
20	690363	Lock, Front Top (2)	51	238088	Hinge, Top (2)			
21		Panel Front	53	691366	Idler & Pulley Assembly			
	3395197	White Biscuit	56	8066065	Belt, Drive			
	3977243	Biscuit	57	348780	Base, Motor			
			58	3400500	Bolt, 5/16–18 x 3/4			
			59	3394341	Pulley, 60 Hz.			
			62	3976707	Motor Assembly 60 Hz.			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LGR7646JQ0, LGR7646JT0
(Designer White) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: LGR7646JQ0, LGR7646JT0
(Designer White) (Biscuit)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	489463	Screw, 8–18 x 5/8
3	3388703	Washer–Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8–18 x 3/8
6	3977373	Bracket, Drum Light
7	3392519	Fuse, Thermal
8	3977358	Drum Hole Plug
9	3387134	Thermostat, Internal–Bias
10	694089	Wheel, Blower (Includes Illus. No. 21)
11	3405016	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10–16 x 1/2
14	3394343	Box, Heater
15	3403140	Thermostat, 205°F (96°C)
18	8066049	Funnel, Burner
19	3403634	Socket Assembly
20	3406124	Bulb
21	3394196	Seal, Blower
22	3402841	Lens, Drum Light
23	487909	Screw, 8–18 x 1/2
24	3406022	Bracket, Bulkhead
25	693995	Screw, 8–18 x 3/8
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8–16
48	3403493	Bulkhead
49	338906	Sensor, Radiant
62	692526	Ring, Bearing
63	97787	Screw, 11–16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal
75	696302	Shield, Exhaust


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3402844 BURNER ASSEMBLY

For Models: LGR7646JQ0, LGR7646JT0

(Designer White) (Biscuit)

1 USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3402844 BURNER ASSEMBLY

For Models: LGR7646JQ0, LGR7646JT0

(Designer White) (Biscuit)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED, TYPE 3 – MANUFACTURED
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	3402844	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8–32 x 5/8)
6	343641	Screw, 10–16 x 1/2
7	693986	Base, Burner
8	3387057	Screw, 8–18 x 3/8 (2)
9		Orifice, Burner
	234826	Type 1
	15775	Type 2
	15419	Type 3
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	3401775	Valve, 60 Hz.
11	694421	Screw, 8–32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	233273	Pipe, Gas Supply
22	3406052	Elbow Union Assembly
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	341029	Clamp, Pipe

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1, 2 & 3)
to Type (4) L.P.G.

BA-141